

Save-A-Pole

Wraps Around poles tightly for reinforcement.



Step 1 - Remove 6-12 inches of concrete from the base of the pole.



Step 3 - Temporarily Secure Metal Stiffener to the pole with Ratchets.



Step 5 - Starting at the base secure metal strapping to the metal stiffener



Step 2 - Wrap Metal Stiffener around the pole



Step 4 - Trim Metal Strapping to fit the pole



Step 6 - After the Stainless Steel Strapping has been secured, the ratchets may be removed to complete the installation.

